

表 21-3 S Mode-0 TDA9332 HV(1)

	TV/AV/ YCbCr(480i)	YPbPr (480P)	YPbPr (720P@60Hz)	YPbPr (1080i@60Hz)
V-Wait *	1A	1A	1A	1A
V-Slope	27	24	25	25
V-Amp	32	31	2F	33
V-Shift	1F	21	23	23
V-Zoom *	19	19	19	19
V-Scroll	1F	1F	1F	1F
V-Cor	1F	12	0F	0B
H-Shift	1A	1D	16	11
H-PARA	07	07	07	08
H-BOW	07	07	09	08
EW-Width	3A	38	38	36
EW-PARA	14	10	10	11
EW-Hcorn	31	16	16	16
EW-Lcorn	3C	27	27	24
EW-Trap	1B	1A	18	1A
EW-EHT	20	20	20	20

表 21-4 S Mode-0 TDA9332 HV(2)

	TV/AV/ YCbCr(576i)	YPbPr (576P)	YPbPr (720P@50Hz)	YPbPr (1080i@50Hz)	VGA (SVGA@60Hz)
V-Wait *	1A	1A	1A	1A	1A
V-Slope	25	21	20	26	23
V-Amp	33	31	24	2F	22
V-Shift	22	21	1C	23	1C
V-Zoom *	19	19	19	19	19
V-Scroll	1F	1F	1F	1F	1F
V-Cor	1F	0C	13	0B	11
H-Shift	17	1D	17	12	0B
H-PARA	07	07	07	08	08
H-BOW	07	07	09	08	08
EW-Width	38	38	34	38	31
EW-PARA	13	10	0D	11	0C
EW-Hcorn	2C	16	1F	1C	20
EW-Lcorn	3A	27	34	24	24
EW-Trap	1B	1A	1F	18	21
EW-EHT	20	20	20	20	20

注: OSD 显示根据实际输入信号源, 每次只出现上述 S Mode-0 两表中相应格式所在列的参数值。