

更多彩电维修资料请到《彩电维修资料网》<http://www.tv160.com> 查询!

[illegible]

更多彩电维修资料请到《彩电维修资料网》<http://www.tv160.com> 查询!

KDT5A	K16J	K16K	K15A	K16G	K10L	KT5A	K16H	K16F	K18D	K18B	K9E	KPT7A
CHD2918	SF2515(A)	PF2939	PF29F50	SF2939	H25K60(B)	DP2915	SF2139	PF2183	SF2591E	SF2170E	DP2998	CHD4395
CHD3498	PF2598	SF2588		SF2539	G2989(B)	DP2998M	PF2139	SF2183	PF2591E	SF1498E	43PDT18	CHD4388
CHD3418	PF2515	SF2539(A)		SF2539A		DP3498M			PF3418E			HP5175
CHD2988	PF2998	SF2911							SF3418E			HP4375
CHD2983	PF2998(A)	SF3411F							PF2593E			
CHD2992(A)	PF2986	PF2588							PF2918E			
	PF2598(A)								PF2991E			
	PF2986(A)											
	SF2951F											
K18E	K12R	K12S	K12FI	K12A	K10L	KPT3A	K9F	K16D	K16F	K12FI	KPT3C	KDT6A
SF2118E	A2111K	H2511K	H1418K	DP29C50	H25K60(B)	DP5188A(H	DP4888	SF2198	PF3498	H1418K	KP5195	CHD3490(A)
PF2118E	H2999KBA			PF29C50	G2989(B)	HP5168	DP4388A	SF2115	SF2583		KP4395	CHD2990
SF2191E	PF2188K					HP4368	DP5189	SF2199	SF2983			CHD2990(A)
	H2111K					HP6188	DP6188	SF2151				
	H2188K					HP5189	DP5188A	SF2119				
						HP5188	DP4388					
						HP5190						
						HP4391A						
		KPT7E	KPT7B	K18J	K18I	KDT6E						
		CHD5195	CHD4011W	PF2955E	PF2993E	CHD3495						
			CHD4311W	SF2566E	PF2193E							
DVD590	DK12A		DVD-P582		DK9B							

更多彩电维修资料请到《彩电维修资料网》<http://www.tv160.com> 查询!

[illegible]