



|   |   |   |   |   |   |   |   |   |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|---|---|---|---|---|---|---|---|---|----|----|----|



5M01电原理图：AV单元

[illegible][illegible]

The schematic diagram for the handset board features the IC8001 (43200Hz 4MHz) as the central component. It is connected to various components and controls as follows:

- Power and Grounding:**
  - VDD is connected to XTAL1.
  - LMOT is connected to XTAL2.
  - SW1, SW2, SW3, SW4, and SW5 are connected to pins 15, 16, 17, 18, and 19 respectively.
  - SW6 is connected to pin 20.
  - SW7 is connected to pin 21.
  - SW8 is connected to pin 22.
  - SW9 is connected to pin 23.
  - SW10 is connected to pin 24.
  - SW11 is connected to pin 25.
- Crystal and Timing:**
  - XTAL1 and XTAL2 are connected to a crystal (X801 43200Hz 4MHz).
  - SW1 and SW2 are connected to a crystal (X802 47p).
  - SW3 and SW4 are connected to a crystal (X803 100).
  - SW5 and SW6 are connected to a crystal (X804 100).
- Control and Output:**
  - SW7 is connected to a control line (W).
  - SW8 is connected to a control line (MENU).
  - SW9 is connected to a control line (LFR).
  - SW10 is connected to a control line (SKAP).
  - SW11 is connected to a control line (SOURCE).
  - SW12 is connected to a control line (PICTURE).
  - SW13 is connected to a control line (VGA).
  - SW14 is connected to a control line (FREETE).
  - SW15 is connected to a control line (VOL-).
  - SW16 is connected to a control line (INEMA).
  - SW17 is connected to a control line (DNR).
  - SW18 is connected to a control line (MODE).
  - SW19 is connected to a control line (Q VIEW).
  - SW20 is connected to a control line (1/11/20).
  - SW21 is connected to a control line (SM PIC).
  - SW22 is connected to a control line (MODE).
  - SW23 is connected to a control line (CH+).
  - SW24 is connected to a control line (ZOOM).
  - SW25 is connected to a control line (CH-).
  - SW26 is connected to a control line (SOUND).
  - SW27 is connected to a control line (STILL).
  - SW28 is connected to a control line (SCAN).

彩电维修资料网  
http://www.tv160.net