







电源部分

键控板和外设板



AV OUT

AV1/AV2/PC/YPbPr Audio			
AV1/AV2	PC	YPbPr	Audio
1	2	3	4
5	6	7	8
9	10	11	12
13	14	15	16