

机型与遥控器对应表

更多彩电资料请到《彩电维修资料网》<http://www.tv160.net> 查询吧！

遥控器型号	对应机型
遥控器上无型号	2119
FC-F11T	2988D, 3409D, 3418D, 3433D
RC-012, RC-021	17"21"一般机型
RC-032, RC-061R, RC-064, RC-091	1419, 9614C, 9621B/C/D, 9625B/BZ, 2968/Z, 2969, 9629B/BZ
RC-033, RC-092	1701, 2128/S, 2129/S, 2566, 2566B, 2568, 2969A。可代RC-012
RC-035	2169, 2509S, 2908
RC-036	2128SZ, 2129SZ,
RC-038	1701AS, 2101AS, 2129A, 2136A, 2166B, 1436A
RC-039	2501C, 2510C, 2511C, 2536C, 2901C, 2909C, C2533。可代RC-040
RC-040	2501A, 2901A, 2909A
RC-041	2919AZ
RC-042	2901C, 2909C, 2966A/C/G。可代RC-039, RC-040
RC-051	9525H, 9529H。可代RC-052, RC-053, RC-098P
RC-052, RC-053	2118Z, 2586Z, 9525, 2986Z, 2989Z, 9329, 9529Z
RC-062GH	9625BGH, 9629BGH
RC-062H	9625BZH, 9629BZH
RC-063N	9625BN, 2969N/1, 9629BN
RC-071	3438, 3438R。可代RC-075, RC-078/B
RC-072	3438D/L, 3438PR
RC-073	3438
RC-074	3438PB
RC-074FP	3438FPR
RC-075	2968SZ
RC-076N1	2966N
RC-078, RC-078B	2952, 2966, 2966GA, 2976S, 3409,
RC-081	3498GH
RC-082, RC-083	2188/SZ, 2989GH
RC-084	2988Z
RC-093	2528/SZ/Z, 2868, 2938Z
RC-094P	2938P
RC-095H	2938GH
RC-096GH	2968GH
RC-097H	2968H
RC-099P	2968P,
RC-099SZ	2938SZ, 2868SZ。可代RC-093
RC-801	VCD302, 302A, 308
RC-803	D603
RC-B01	1436A, 2101C, 2136C/W, 2169C, 2178A。可代RC-031, RC-038, RC-A01C
RC-B02T	2139A
RC-B03T	2133, C2133
RC-B06T	2102, 2136A, 2156A, 2169A
RC-B07T	2106A, 2135A
RC-C01T	2116E, 2118E, C2133E, 2175E, 可代RC-C07T
RC-C04T	2966GL
RC-C07T	2113E, 2188EB
RC-C08T	2513E, 2518E/EW, 2913E/EB
RC-C09T	2502, 2907, 2909B,

机型与遥控器对应表

更多彩电资料请到《彩电维修资料网》<http://www.tv160.net> 查询吧！

遥控器型号	对应机型
RC-C10T	2906E, 2918E/EW, 2977E
RC-C11T	2506A, 2535A, 2906A
RC-C14T	2113T/TW
RC-C202	CVD900
RC-D001	DVD2500
RC-E01D	DVD2000
RC-E03T	2111D, 2136D/G, 2139D, 2975D
RC-E04T	2511DZ, 2910DZ, 2911DZ, 可代RC-E05T
RC-E05T	2910, 2910D, 2911D, 2916D, 2939D/DR/H
RC-E06T	2511DR, 2516B/D, 2539D/DR
RC-E07T	2511DI, 2511DZ, 2515DZ
RC-E08T	DTV2912
RC-E09T	2111DI
RC-E11T	2511DI
RC-E13T	2180G
RC-E16T	2510G, 2536G, 2575D, 2580DB, 2588DB, 2910G, 2911, 2927D, 2956D, 2980DB, 2988DB
RC-E18T	AT2115, AT2170B/D, AT21D59, AT2575D, AT2588D, AT2988D
RC-E19T	2175DI
RC-E20T	AT2586, AT2590, AT2590
RC-E27T	2915DZ
RC-E30T	2502D
RC-E33T	2136G (游戏在遥控器上)
RC-E34T	2502D (游戏在遥控器上)
RC-E35T	2927D(游戏在机上)
RC-E39T	2116DI
RC-E41T	AT2927i, AT2935i, AT2970i
RC-E43T	AT2956B
RC-E47T	AT2975D
RC-E49T	3406D, 34D106,
RC-E54T	AT25A192
RC-E59T	2927D
RC-F01T	3811DI
RC-F02T	2580G, 2588BD, 2916DZ, 2980G, 2988BD, B2980
RC-F04T	2580G, 2588BD,
RC-F06T	2916D, 3488D
RC-F09T	3416DI, 3480GI。可代RC-F01T, RC-F02T, RC-F10T
RC-F10T	3416, 3416D, 3460D, 3486, 3488D, 34D106
RC-F11T	2988D, 3418D
RC-F13T	2988DI
RC-F14T	3488D, AT3480GI, AT3486DI/DZ, AT3488DZ
RC-F15T	AT2986Z, AT3486DZ
RC-F18T	2999UZ
RC-F21T	AT2570B, AT2570U
RC-F22T	AT2516U, AT2916U, AT2927U
RC-F25T	AT2965U, AT34U186, 可代RC-F18T, RC-F22T
RC-F26T	AT3416U
RC-F28T	1475S, AT2110G, AT21S135,

机型与遥控器对应表

更多彩电资料请到《彩电维修资料网》<http://www.tv160.net> 查询吧！

遥控器型号	对应机型
RC-F30T	AT25S135
RC-F31T	AT2570U, AT25U159, AT2970U, AT29U159
RC-F34T	AT21S179, AT21S192
RC-F38T (228频道)	AT2965U, AT34U186, 可代RC-F39T, RC-F40T, RC-F41T, RC-F43T
RC-F39T	2999UZ (228频道)
RC-F40T	AT3416U (228频道) (不含智能音量键)
RC-F41T	29U186Z/ZG,
RC-F42T	AT2916U (228频道)
RC-F43T	AT2570U, AT25U159, AT2970U, AT29U159 (228频道)
RC-F47T	HiD2992i
RC-F48T	AT2590UB, AT2990U
RC-F50T	1475S (另有手机型一种)
RC-F51T	AT2190U
RC-F54T	
RC-F55T	AT2570UB, 可代RC-F62T, RC-F63T
RC-F59T	2927D
RC-F61T	AT2965
RC-F62T	AT25106B, AT2960B, AT2975/B
RC-F63T	AT2590UB, AT25S135, 可代RC-F62T
RC-F64T	2927U
RC-G01T注: 有两种	HiD299.p, HiD2991.p, HiD299s.p, HiD348.p, HiD348S.p
RC-G01T	HiD2990p, HiD29166p
RC-R02T	AT25166G, AT29166G, 可代RC-R05T
RC-R05T	AT2960B
REM-1	TD-S950
REM-11	TD-V120, TD-V150
REM-111	DVD-3000
无型号#	DTV2000
中文图文电视	2966T
聪明电眼电视	AI 2560, AI 2960